



The CaptureSMB process principle





CaptureSMB process principle


Loading of a batch column





• With CaptureSMB

















<u>Step 1:</u>


Feed & wash

Step 2:

- elute product
- feed column

Step 3:

- CIP & re-equil.
- feed column



<u>Step 1:</u>


Feed & wash


<u>Step 2:</u>


- elute product
- feed column


Step 3:

- CIP & re-equil.
- feed column









<u>Step 1:</u>

Feed & wash

<u>Step 2:</u>


- elute product
- feed column

Step 3:

- CIP & re-equil.
- feed column

Start over

Overview CaptureSMB



Repeated after startup

Only once for

startup